

MIDIkeys The only solderless MIDI interface for the KORG Volca Keys.

MIDI Implementation Chart

Control Change

Name	CC#
KICK LEVEL	40
SNARE LEVEL	41
LOW TOM LEVEL	42
HIGH TOM LEVEL	43
CLOSED HH LEVEL	44
OPEN HH LEVEL	45
CLAP LEVEL	46
CLAVES LEVEL	47
AGOGO LEVEL	48
CRASH LEVEL	49
CLAP PCM	50
CLAVES PCM	51
AGOGO PCM	52
CRASH PCM	53
STUTTER TIME	54
STUTTER DEPTH	55
TOM DECAY	56
CLOSED HH DECAY	57
OPEN HH DECAY	58
HH GRAIN	59

Note

Part	Note#
KICK	C1
SNARE	D1
LOW TOM	G1
HIGH TOM	D2
CLOSED HH	F#1
OPEN HH	A#1
CLAP	D#1
CLAVES	D#4
AGOGO	G3
CRASH	C#2